

FILL IN PROPER DESIGNATIONS TO DETERMINE PRODUCT NUMBER: A 5 1 - - S - - E

1 = Time Initiated  
2 = Impulse Initiated

**PROGRAM**     Stager Program to be Provided  
6 = 6 Position Softener with Timed Brine & Refill  
7 = 5 Position Softener with Timed Brine Draw  
9 = 5 Position Softener with Timed Brine Refill  
10 = 2 Tank Sequential Filter, Backwash & Rinse  
11 = 5 Position Filter with Draindown & Air Scour  
86 = 6 Tank Sequential Filter, Backwash Only  
87 = 7 Tank Sequential Filter, Backwash Only  
SS = Special Stager Program. (See Stager Custom Program Price Adder)

**FEATURES**  
1 = NEMA 1 Std. Panel & Enclosure  
4 = NEMA 4 Std. Panel & Enclosure  
F = NEMA 4X Fiberglass Panel & Enclosure

**ELECTRICAL**     FEATURES  
1 = 115 Volts / 60 Hertz, Standard  
2 = 220 Volts / 50 Hertz  
4 = 220 Volts / 60 Hertz  
5 = 24 Volts / 50 Hertz

**1<sup>st</sup> AUX. SWITCH**     First Extra Switch to be provided on Rotary Pilot Stager  
S = Homing, Standard

**2<sup>nd</sup> AUX. SWITCH**     FEATURES  
0 = NONE  
\*A to H = CAM POSITION Switch is to be active  
  
\* Use SPECIAL DRAWING number if active in more than 1 position.  
\* Use a Letter to indicate Cam position Not a Number, See DWG. NO. 1078031.

**PRESSURE**     Program of Stager  
0 = STANDARD (Vent to Open for Use with Normally Open Valves)  
1 = INVERTED (Pressure to Open for Use with Normally Closed Valves)

**REGEN FREQUENCY**     FEATURES  
Maximum Days Between Regeneration  
0 = Impulse Timers Only, Model A251 only  
6 = 6 Day Timer, Model A151 only  
7 = 7 Day Timer, Model A151 only  
P = Push Button, Model A251 only

