

# 1.27

# A158 & A258 CONTROLLER

FILL IN PROPER DESIGNATIONS TO DETERMINE PRODUCT NUMBER:

A 5 8 - - S C

- 1 = Time Initiated
- 2 = Impulse Initiated

**PROGRAM** Stager Program to be Provided

- 3 = 3 Tank Sequential Filter with Backwash & Rinse
- 4 = 4 Tank Sequential Filter with Backwas & Rinse
- TA = Two Tank Alternating Soltners
- SS = Special Stager Program.

**FEATURES**

- 1 = NEMA 1 Std. Panel & Enclosure
- 4 = NEMA 4 Std. Panel & Enclosure
- F = NEMA 4X Fiberglass Panel & Enclosure

**ELECTRICAL** FEATURES

- 1 = 115 Volts / 60 Hertz, Standard
- 2 = 220 Volts / 50 Hertz
- 4 = 220 Volts / 60 Hertz

**1<sup>st</sup> AUX. SWITCH** First Extra Switch to be provided on Rotary Pilot Stager

- S = Homing, Standard, All Modes except TA
- W = Butterfly Cam, to control status lights Model TA Only

**2<sup>nd</sup> AUX. SWITCH**

FEATURES

- 0 = NONE, All Models except TA
- S = Model TA Only
- \*A to R = CAM POSITION Switch is to be active (Not Available on ModelTA)

\* Use SPECIAL DRAWING number if active in more than 1 position.

\* Use a Letter to indicate Cam position Not a Number, See DWG. NO. 1078031.

**PRESSURE** Program of Stager

- 0 = STANDARD (Vent to Open for Use with Normally Open Valves)
- 1 = INVERTED (Pressure to Open for Use with Normally Closed Valves)

**REGEN** FEATURES

**FREQUENCY** Maximum Days Between Regeneration

- 0 = Impulse Timers Only, Model A258only
- 6 = 6 Day Timer, Model A158 only
- 7 = 7 Day Timer, Model A158 only
- P = Push Button, Model A258 only

